

Shortcut	Function
Power + Start + Select	Reboot
Power + Select	Kill current app
Power + UP	Volume up
Power + DOWN	Volume down
Power + RIGHT	Brightness up
Power + LEFT	Brightness down
Power + A	Hardware scaling ratio mode
Power + B	Mouse mode
Power + Y	Sleep mode (Power to resume)
Power + X	Take screenshot
A (while powering on)	Skip logo and show init logs

Screenshots are saved in your home directory inside the ~/screenshots folder.

Shortcut	Function
Select + A	Pause
Select + B	Reset
Select + X or Power	RetroArch Menu
Select + Y	Fast forward
Select + R1	Savestate save
Select + L1	Savestate load
Select + R2	Swap disc
Select + L2	Open CD tray
Select + Start	Quit
Select + Left/Right	Change savestate slot
Select + Up/Down	Volume change
Hold Start	UniBIOS settings
R2 or R3	(Also works on Neo Geo FBA) Test menu on some games (Also works on CPS2)

## Other Commands

### FBA (MAME, FBA y CPS)

L1 + R1 + Start	Emulator menu and Quit
L1 + R1 + Y	Show/hide FPS counter

### xMAME

Select + L1 + R1	Quit
Start + R1	Show/hide FPS counter

### Daphne

L1	Insert coin
Start	Start game
Select	Quit

### PocketSNES (SNES)

Select + Start or Power	Emulator menu and Quit
-------------------------	------------------------

### ReGBA (GBA)

Select + Start or Power	Emulator menu and Quit
-------------------------	------------------------

### PCSX4All (PlayStation)

Select + Start or Power	Emulator menu and Quit
-------------------------	------------------------

### JzIntv

Select	Emulator menu and Quit
Power	Quit
R1	Virtual controller
L1	Virtual keyboard

### ColecoD (ColecoVision)

Select + Start	Emulator menu and Quit
----------------	------------------------

### Tac08 (PICO8)

Start	Emulator menu and Quit
-------	------------------------

### Fuse (ZX Spectrum)

Select	Virtual keyboard
--------	------------------

### Cap32 (Amstrad CPC)

Y + Start	Virtual keyboard. Once shown, open/close the RA menu (Select + X) so that the left stick works as a mouse
-----------	---

### Vice 64 (C= 64)

Select	Virtual keyboard
--------	------------------

### PUAE (Amiga)

L1	Virtual keyboard
----	------------------

### BeebEm (BBC Micro)

L1	Emulator menu and Quit
R1	Virtual Keyboard

## SimpleMenu Commands

Shortcut	Function
Start	Brings up the Settings screen
Select	ROM options. Select autolaunch, emulator and overclocking
Up	Selects the previous game/section/group
Down	Selects the next game/section/group
Left	Skips to the previous page in the current section
Right	Skips to the next page in the current section
R1	Switches between menu and fullscreen mode
R2	Refreshes the current section
A	Launches a game/program
B	Press once to go back a screen, hold to use as hotkey
X	Marks ROM as favorite in regular sections. In Favorites section, removes ROM.
Y	Goes to the Favorites section
B + Left	Skips to the previous letter
B + Right	Skips to the next letter
B + Up	Goes to the previous section, skipping logo
B + Down	Goes to the next section, skipping
B + Select	Random select
B + X	Deletes the selected rom with NO CONFIRMATION.
B + A	Runs emulator without loading a ROM, if it supports it.